

EFMB Test Score Sheet COMMO — LOAD FH/COMSEC DATA AND CONDUCT RADIO CHECK USING SINGGARS (ASIP) (For use of this form, see AMEDDC&S HRCOE Pam 350-10, the proponent is MCCS-OPE)		
CANDIDATE'S RANK AND NAME	CANDIDATE #	
TASK: LOAD FH/COMSEC DATA AND CONDUCT RADIO CHECK USING SINGGARS (ASIP).		
CONDITIONS: Given a SINGGARS radio (AN/PRC-119E/F) with components, a battery, SKL loaded with signal operation instructions (SOI) and FH/COMSEC data and a W-4 cable, an operating frequency, a call sign, and the receiving station's call sign.		
STANDARDS: Load radio for single channel secure operations and complete a radio check within 10 minutes.		
NOTE: THIS TASK HAS BEEN MODIFIED FOR EFMB TESTING PURPOSES ONLY.		
PERFORMANCE STEPS/MEASURES	GO	NO-GO
1. Set "FCTN" to "TST." Wait for "GOOD" on display.		
2. Set "FCTN" to "LD."		
NOTE: Steps 1 and 2 may be skipped if this task is performed after "Assemble and Operate a SINGGARS (ASIP)" task.		
3. Set "COMSEC" to "CT" via "MENU" key.		
4. Set "MODE" to "FH" via "MENU" key.		
5. Press handset twice to clear audio alarm in handset to solid tone.		
6. Load FH/COMSEC.		
a. Using the SKL:		
(1) Turn the SKL on and double click "CoreLib." Logon will appear.		
(2) Type in User ID and password. Click "OK."		
NOTE: For EFMB testing purposes the evaluator will provide the User ID and password to the candidate.		
(3) Select the "Launch Tab" at the top of the screen.		
(4) Select "Launch UAS." "SKL" will be highlighted. Click "OK."		
(5) Start up information will appear. Select "OK."		
(6) Select the "Plats" tab. Select "SINGGARS." With "SINGGARS" highlighted, select "Load" icon at top right of screen.		
(7) Select "Non-ICOM Transfer." Select "Include Time." Select "OK." "RT-1523" should appear. Select "Next."		
(8) Profiles page should appear. Check each task box as it is performed.		
(9) Connect the SKL to the SINGGARS (ASIP) with the W4 Cable.		
(10) Select "Send" on the SKL and press "LOAD" on the "RT."		
7. Set "CHAN" to desired channel via "MENU" key.		
8. Press "FREQ," then "CLR" on the keypad.		
9. Enter the frequency given and press "STO" on the keypad.		
10. Set "RF PWR" to desired setting ("LO", "M", or "HI").		

AMEDDC&S HRCOE PAM 350-10

11. Set "FCTN" to "SQ ON."				
12. Conduct radio check using proper procedures and prowords.				
13. Complete all required performance measures within 10 minutes.				
14. Met all administrative requirements for this task				
EVALUATOR WRITES: TIME REQUIRED TO PERFORM TASK:				
REASON(S) FOR FAILURE	DOES THE CANDIDATE WISH TO REBUT THIS TASK? (CANDIDATE INITIALS APPROPRIATE BOX)	<table border="1"> <tr> <td data-bbox="1281 428 1401 499">YES</td> <td data-bbox="1401 428 1526 499">NO</td> </tr> </table>	YES	NO
YES	NO			
LANE OIC/NCOIC INITIALS	EVALUATOR'S SIGNATURE	DATE		